




Voodoo3™ SGRAM Model Information



You may have received a new model of the Voodoo3 card that uses Synchronous-Graphics-RAM (SGRAM) instead of Synchronous-DRAM (SDRAM) as described on the box and in the Quick Install Guide and other 3dfx documentation. The new SGRAM version of the Voodoo3 card has all of the same great features, capabilities, and performance of the SDRAM version, so the only difference is in the physical layout of the card itself.

Compare your Voodoo3 card to the board diagram (below) to see if it is an SGRAM model. Whether your model of the Voodoo3 card is based on SGRAM or SDRAM, you can still use the instructions and information in the Quick Install Guide, the online manual, and other 3dfx documentation to install and use your powerful new Voodoo3 accelerator card.



The Voodoo3 SGRAM Card

Voodoo3 SGRAM Board Diagram

The diagram above shows the differences between the AGP and PCI versions of the Voodoo3 SGRAM card. Note the locations of the Monitor Connector and the Digital Video Input Connector on your new Voodoo3 card. Also, check to be sure that your model of the Voodoo3 card has the proper type of expansion slot connector (AGP or PCI) for use in your system.